



**The Accu-Feed AGF (Advanced Guidewire Feeder)** can make ten or more guidewires from a single input wire. Our AGF with in-line cutter paired with your centerless grinder can now feed, grind and cut your guidewires to precise lengths from 10-400cm. ASG integrates the AGF and our entire family of feeders with cutting, measurement, assembly, welding, marking, and testing subsystems to your specifications.

### Features:

- Two process steps in one saves labor, floor-space, and cycle time
- Faster throughput means more output with fewer grinders
- Precise cutoff helps you meet tighter customer specs
- Less wire scrap increases your bottom line
- Computer control with color touch screen
- Automatic setup using bar code recipe selection
- Max wire length of 2, 3, or 4 meters
- Super precise wire position feedback to your profile grinder
- Every wire is measured during processing
- Also feeds small diameter catheters and tubing

Contact ASG Medical Systems for additional information