

ASG Medical Systems
3874 Fiscal Ct., Suite 100
West Palm Beach, FL 33404

25 May 2009

Press Release

ASG Medical Systems, LLC is pleased to announce our NEW Heavy Duty Low Tension Dereeler (HD LTD)!

ASG Medical Systems, LLC remains in the forefront of the Medical Device Industry technology with its introduction of our **new Heavy Duty Low Tension Dereeler (HD LTD)**!

The Heavy Duty Low Tension Dereeler (HD LTD) is the latest and greatest in dereeling technology and the newest member of our leading-edge Accu-Reel family. The HD LTD is a computer controlled dereeler designed to provide low force, constant tension payout of tubing into a high volume, critical tolerance manufacturing operation, such as our Accu-Cut medical tubing cutters.

The HD LTD features a proportional speed controlled, low mass dancer arm that has switch selectable dual speed ranges; with the speed and tube tension being auto-adjusted by the computer. The all digital dancer arm control has no mechanical switches or pots to wear out, and precision ball bearing construction keeps friction extremely low. The unit is torque limited for safety and can be employed without electrical connection to the companion machine

The HD LTD is similar to our earlier LTD in design and function with one "large" difference. As seen in the photo, the HD LTD handles very large spools of tubing, far greater than the original LTD's 21" limit. Think how the HD LTD can efficiently automate dereeling in your manufacturing operation today!



[Heavy Duty Low Tension Dereeler \(HD LTD\)](#)

sales@asgmedical.com

561-848-6684

www.asgmedical.com